



Technical Bulletin 140

Version 1.0 23rd April 2013

Software and Firmware update for Select and Tiger

New Tiger software and firmware is now available. Please see the list of improvements below:-

Tiger instrument firmware (V4.20)

868: The Tiger automatic zeroed after a calibration, this has been removed. (Improvement)

951: Processor temperature was removed from the 'info' screen as it was wrongly assumed to be ambient temperature. (Improvement)

976: The Tiger Select 40 ppm range restriction has been removed to show a wider working range in tube mode. (Improvement)

TigerPC software (V1.0.0.70)

869: SPAN 2 resolutions in custom cal has been extended to 0.1 ppm resolution (Improvement)

882: TigerPC crashed when 12 features were place in one column, now resolved (Bug)

899: User manual download button address incorrect (fixed)

905: Install driver resolved with MS Windows 8 (Bug)

910: Alternative messages to help the user (Improvement)

975: Data graphs are now exportable as jpg. Image files. (Improvement)

Please see the latest Tiger and Select manuals available to download from our website.

Kind regards,

Alex Wadey-Leblond
Sales and Marketing Coordinator