



Technical Bulletin TB-183

Version 1.0 06/11/2017

Updated Tiger & Tiger Select firmware, PC software and Tiger Select Manual

The Tiger and Tiger Select firmware and PC software has been updated with a number of enhancements. Please install the new versions below to ensure you are up to date.

Please be aware that there are significant changes to the Tiger Select firmware, therefore, we would advise reviewing the latest user manual prior to completing the updates.

- Tiger & Tiger Select firmware version: V0.8.08
- Tiger & Tiger Select software version: V1.0.1.07

The improvements that have been made within this release are detailed below.

Tiger & Select

Run time is now clearly displayed in hours and minutes.

Tiger PC configuration screen can be expanded or minimised to simplify the information displayed.

Gases added to the custom gas tables are selected as default.

Ion Science logo can be restored.

Tiger Select only

Basic and Advanced modes are now selectable within the instrument firmware. Please refer to the latest user manual for more information.

The 10.0eV lamp is the only selectable lamp option.

Tube calibration error occurs when insufficient calibration is completed.

Tube and PID calibration routines have been updated for better clarity.

For more information contact

E: marketing@ionscience.com

T: +44 (0)1763 207206

Unrivalled Gas Detection.
ionscience.com





Tiger Select Manual

There have been a number of updates to the Tiger Select manual. Please [download V3.0](#) from the downloads section of the product page on our website.

For more information on the updates, please refer to the log at the back of the manual.

For more information contact

E: marketing@ionscience.com

T: +44 (0)1763 207206

Unrivalled Gas Detection.
ionscience.com

